PC AUTOMATION 26 INSTALLATION GUIDE

1. Installation/update on individual PC

   Execute PCSCHEMATIC_Automation_26_x_x_x.exe

   Follow the on-screen instructions in the setup program

2 Installation/update on Terminal Server/Citrix Server

   Change terminal server user mode from execute to install (change user /install)
   Execute PCSCHEMATIC_Automation_26_ x_x_x.exe
   Follow the on-screen instructions in the setup program.
   Check that users have write-access to all folders under the PCAutomation folder
   Change terminal server user mode from install to execute (change user /execute)
   Please note that Automation requires a Net license when it is running on a terminal server – see section 5 for installation of License server software.

3 Installation/update as multiuser installation on network drive

   Execute PCSCHEMATIC_Automation_26_ x_x_x.exe

   Follow the on-screen instructions in the setup program.

   When the program is installed, do the following on all PC's from which you want to use PC Automation: Execute Pcselcad.exe from the PCAutomation folder on the network, which was created during the installation of the program. If necessary, you can also create a shortcut to the Pcselcad.exe file.

4 Silent installation/update.

   The following command line switches can be used when running the installation / update silent:

-gm2	Selfextracter runs silent
/q	PCSCHEMATIC setup runs silent – but creates a log file in temp%
/i	Installs new version
/I:<path>	Installs new version at <path>
/u	Updates existing version
/u:<path>	Updates existing version at <path>

   To make a silent installation on c:\PCAutomation
   Execute PCSCHEMATIC_Automation_26_x_x_x.exe -gm2 /q /i

   To install on a specific path – e.g. in the folder d:\automation
   Execute PCSCHEMATIC_Automation_26_x_x_x.exe -gm2 /q /i:d:\automation

   To make a silent update on a PCAutomation folder (if you only have 1 installation of Automation)
   Execute PCSCHEMATIC_Automation_26_x_x_x.exe -gm2 /q /u

To update an existing installation – e.g. in the path d:\automation
Execute **PCSCHEMATIC_Automation_26_x_x_x.exe -gm2 /q /u:d:\automation**

5 Installation of PCS License server

a. Go to https://www.pcschematic.com/en/downloads/pc-automation/#other
b. Select **PCS License Server**
c. Download **PCS License Server**
d. Execute the downloaded program, and follow its on-screen instructions

6 Download links

You can download the PC Automation software here:
https://www.pcschematic.com/en/downloads/pc-automation/