

Automation Ver 22.0.10.4 Changes and Improvements

Version 22.0.10

SOD-1765 Error when exporting DWG file with arcs

SOD-1764 Drawing headers also includes French states.

Version 22.0.9

SOD-1759 Missing textupdate for symbol datafields with rds-designations and descriptions

SOD-1755 Components with more than one symbols are allowed to change symbol states. This is not allowed from ver 22.

SOD-1752 Text alignment bug when placing reference frames

SOD-333 Options Module: Measurements is not deleted

AUTO-7428 [Improvement] Excel exports in Mounting Assistant includes page numbers

AUTO-7407 [Improvement] Pagemenu: ArticleData changed to RDS/ArticleData to unveil the hidden function

AUTO-7289 [Improvement] Black background: Filled out connection points can't be seen, eg external side of terminals

Version 22.0.8

AUTO-6840 [Improvement] Export DWG: By export, the individual pages number is requested to be part of the DWG file name.

Version 22.0.7

SOD-1722 After using 'Align' function, focus on symbols is lost

AUTO-7385 [Improvement] Individual text properties has been added to Wirenumber name and Signal name. Beware, fonts are reset to PCSHEMATIC font!

AUTO-7369 [Improvement] Single list on a page has been expanded also to include a PLC list

Version 22.0.6

SOD-1709 Mechanical Load did not remember the text for selecting symbols

SOD-1700 RDS names with / caused problems, when renaming.

SOD-327 Objectlister: Lock List to Referencedesignation ignore the selected designation switching between tabs (e.g Terminal to Symbol.)

AUTO-7094 [Improvement] Improve drawing of complex layouts when moving

Version 22.0.5

SOD-1686 Very slow generation of symbol documentation

Version 22.0.4

SOD-1662 Mounting assistant: Crash after deleting note.

SOD-1654 Angled texts with filled background has been fixed

SOD-1645 Symbols of type Terminal can not be treated in the Component Wizard

SOD-1441 Object Lister: When editing IO address, program failure may occur.

SOD-1409 Component, Signal data: The button All (Make change for all) is not displayed.

AUTO-7327 Possibility to shutdown Automation from within a module

AUTO-7300 Project generator has become very slow.

AUTO-7005 Insert Signal symbol on left side of the line caused the line to be only 1 pixel long.

Version 22.0.3

SOD-1642 Line texts settings did not follow the UPPERcase/lowercase setting

SOD-1641 PLCTerminals are showing up twice on terminal list.

SOD-1637 Service program: Possible to change component group number on terminals.

SOD-1636 Object lister: Symbol type Normal with connection terminals on terminal list is treated as terminals and shown on Terminal tab

SOD-1635 Show Terminal Row now includes Normal symbols with connection terminals on terminal list

SOD-1629 Magnitic snap, doesn't work with rotated objects.

SOD-1383 Undo does not work when rotating symbols with reference on connection points.

AUTO-2044 It is possible to change connection information and save it in DSBSservice.

Version 22.0.2

SOD-1631 References between symbols are not present after loading project.

SOD-1597 Terminal symbol 03-02-02 had wrong text alignment. This is now fixed - all texts are adjusted to the right.

Version 22.0.1

SOD-1604 Crash: Magnetic placement

SOD-1589 Crash ved paint a Datafelt

SOD-1588 Readonly warning dialog disabled when open pro files with cmd file for FileSaveAs and FilePrint commands.

SOD-1587 Vælg noget fra Pickmenuen

SOD-1586 Åbner et projekt, crash.

SOD-1585 Sletning af referencebetegnelser

SOD-1580 Specialindstillinger mm. (enkelte option er disablet)

SOD-1568 Some datafields did not update after update request with CW's multi-edit function

SOD-1564 Crash ved load a projekt, som er nyere and Automation's version

SOD-1562 Replace symbol can select states on replacing symbol

SOD-1560 Crash ved gem (Tegningshoved indeholder datafelt som peger på billede)

SOD-1552 In rare cases a warning dialog about accessory's main component was shown when a project was opened

SOD-1544 Crash in cable plan module after closing the project

SOD-1542 Eurokalog was not working on graphical plans

SOD-1530 Jumpers between two columns are not shown appropriately in the terminal list

AUTO-7241 [Improvement] In PanelBuilder: Customer's request for new components is changed from pure text to a link to our [www](#)

AUTO-7229 [Improvement] The PRO-filetype will only be registered to Cabledim when it has no previous registration

AUTO-7223 Crash without warning when creating a connection plan when on a connection plan

AUTO-7184 Component menu can indicate error with double article no, when the article no is ok

AUTO-7104 Tegningshoved: Gentagelser virker ikke på alle felter