

Automation Ver 22.1.7.15 Changes and Improvements

Version 22.1.7

SOD-1965 Crash when importing DWG-file
SOD-1961 Edit symboldatafields module, crashes if no project are open.
SOD-1956 Objekt lister highlights incorrectly when using Symbol data fields
SOD-1953 F4 could course a program crash
SOD-1937 'All' Text/Symbol defaults are not transferred correctly with the Project Generator. SOD-1925 Rare crash when 'Show Component' is active
SOD-1921 Crash when selecting component followed by changing the reference designation
SOD-1920 "Change path"-button in URL-links, don't work as expected
SOD-1908 Part -/Component list: Choose "=-design." in "Setup/Criteria" press on = sign on the keyboard (crash)
SOD-1903 Export to DWG: Incorrect first page number while displaying DWG / DXF export
SOD-1828 Symbol reference disapear on Main reference symbol when exporting to PDF til PDF and Updating references
SOD-1619 Invalid port number in License setup could lead to crash
SOD-1267 Page menu: When changing the reference name on several pages at a time, RDS on symbols does not change.
AUTO-7837 [Improvement] Objektlister kan underopdele symbolers datafelter
AUTO-7836 Rediger symbolers datafelter: Håndtering af flere Excelark
AUTO-7835 RedigerSDF-modul: Se ændringer i forhold til aktivt produkt.

Version 22.1.6

SOD-1869 Edited a symbol, from the symbolmenu can take a long time updating symbol-graphic.
SOD-1865 Replace symbol with symbol datafields is now only possible, when the symbol datafields are present in the symbol library's symbol (libtype) AUTO-7774 Crash when Replace symbol with different symbol datafields followed by modifying the symbol data fields
AUTO-7769 Crash after selecting and changing an object AUTO-6547 Crash ved kopiering af side

Version 22.1.5

SOD-1858 Crash: Create Component list file, and click the Settings button

Version 22.1.4

SOD-1853 Ref. designation description: Missing conversion of text in ref. designation frame
SOD-1852 The Objectlister can deselect a ref. designation
SOD-1848 Crash when deleting a symbol datafield text in one symbol of a selection of symbols
SOD-1847 Optional Accessory: Qty over 100 is automaticly changed back 100 qty SOD-1845 Name and RDS mess with multilayer terminals
SOD-1835 Pin sequence is not always respected by Component Wizard
SOD-1834 PLC-name was not shown in the Select IO-adress window
AUTO-7690 Components with more that one symbol cannot be defined to have connections on term-lists
AUTO-7687 [Improvement] Terminals' position numbers must be able to exceed 9
AUTO-7683 [Improvement] Non-electrical on Mec symbols leads to wrong color codes in the list
AUTO-7661 Incorrect mapping to database leads to crash
AUTO-7643 Signal reference text was fixed to PCS font

Version 22.1.3

SOD-1830 Terminal connection list is ok with internal/side 1 connections only
SOD-1829 Busbars may also have accessories now
SOD-1819 Administrator program doesn't read pcssys.ini
SOD-1811 Dividers is not copied correctly in some instances
AUTO-7585 Copy/Paste doesn't show the copied area correctly
AUTO-7579 ACAD.map files are now with 'mm' or 'inch' for better import functions.

Version 22.1.1

SOD-1800 'Vis hele referencebetegnelsen' virker ikke for referancerammer
SOD-1760 PDF Export moved some text positions (true type fonts)

Version 22.1.0

SOD-1792 Automation is ignoring borrowed licenses is some cases.
SOD-1787 Error in Patch and Updates detection for updates send from Administrator Program

Version 22.0.12

SOD-1760 PDF Export moved some text positions (true type fonts)
AUTO-6547 Crash ved kopiering af side

Version 22.0.10

SOD-1765 Error when eksporting DWG file with arcs
SOD-1764 Drawing headers also includes French states.

Version 22.0.9

SOD-1759 Missing textupdate for symbol datafields with rds-designations and descriptions
SOD-1755 Components with more than one symbols are allowed to change symbol states. This is not allowed from ver 22.
SOD-1752 Text alignment bug when placing reference frames
SOD-333 Options Module: Measurements is not deleted
AUTO-7428 [Improvement] Excel exports in Mounting Assistant includes page numbers
AUTO-7407 [Improvement] Pagemenu: ArticleData changed to RDS/ArticleData to unveil the hidden function
AUTO-7289 [Improvement] Black background: Filled out connection points can't be seen, eg external side of terminals

Version 22.0.8

AUTO-6840 [Improvement] Export DWG: By export, the individual pages number is requested to be part of the DWG file name.

Version 22.0.7

SOD-1722 After using 'Align' function, focus on symbols is lost
AUTO-7385 [Improvement] Individual text properties has been added to Wirenumber name and Signal name. Beware, fonts are reset to PCSCHEMATIC font!
AUTO-7369 [Improvement] Single list on a page has been expanded also to include a PLC list

Version 22.0.6

SOD-1709 Mechanical Load did not remember the text for selecting symbols
SOD-1700 RDS names with / caused problems, when renaming.
SOD-327 Objectlister: Lock List to Referencedesignation ignore the selected designation switching between tabs (e.g Terminal to Symbol.)
AUTO-7094 [Improvement] Improve drawing of complex layouts when moving

Version 22.0.5

SOD-1686 Very slow generation of symbol documentation

Version 22.0.4

SOD-1662 Mounting assistant: Crash after deleting note. SOD-1654 Angled texts with filled background has been fixed
SOD-1645 Symbols of type Terminal can not be treated in the Component Wizard
SOD-1441 Object Lister: When editing IO address, program failure may occur.
SOD-1409 Component, Signal data: The button All (Make change for all) is not displayed.
AUTO-7327 Possibility to shutdown Automation from within a module
AUTO-7300 Project generator has become very slow.
AUTO-7005 Insert Signal symbol on left side of the line caused the line to be only 1 pixel long.

Version 22.0.3

SOD-1642 Line texts settings did not follow the UPPERcase/lowercase setting
SOD-1641 PLCTerminals are showing up twice on terminal list.
SOD-1637 Service program: Possible to change component group number on terminals.
SOD-1636 Object lister: Symbol type Normal with connection terminals on terminal list is treated as terminals and shown on Terminal tab
SOD-1635 Show Terminal Row now includes Normal symbols with connection terminals on terminal list
SOD-1629 Magnitic snap, doesn't work with rotated objects.
SOD-1383 Undo does not work when rotating symbols with reference on connection points.
AUTO-2044 It is possible to change connection information and save it in DSBSservice.

Version 22.0.2

SOD-1631 References between symbols are not present after loading project.
SOD-1597 Terminal symbol 03-02-02 had wrong text alignment. This is now fixed - all texts are adjusted to the right.

Version 22.0.1

SOD-1604 Crash: Magnetic placement
SOD-1589 Crash ved paint a Datafelt
SOD-1588 Readonly warning dialog disabled when open pro files with cmd file for FileSaveAs and FilePrint commands.
SOD-1587 Vælg noget fra Pickmenuen
SOD-1586 Åbner et projekt, crash.
SOD-1585 Sletning af referencebetegnelser
SOD-1580 Specialindstillinger mm. (enkelte option er disabled)

SOD-1568 Some datafields did not update after update request with CW's multi-edit function
SOD-1564 Crash ved load a projekt, som er nyere and Automation's version
SOD-1562 Replace symbol can select states on replacing symbol
SOD-1560 Crash ved gem (Tegningshoved indeholder datafelt som peger på billede)
SOD-1552 In rare cases a warning dialog about accessory's main component was shown when a project was opened
SOD-1544 Crash in cable plan module after closing the project
SOD-1542 Eurokalog was not working on graphical plans
SOD-1530 Jumpers between two columns are not shown appropriately in the terminal list
AUTO-7241 [Improvement] In PanelBuilder: Customer's request for new components is changed from pure text to a link to our www
AUTO-7229 [Improvement] The PRO-filetype will only be registrered to Cabledim when it has no previous registration
AUTO-7223 Crash without warning when creating a connection plan when on a connection plan
AUTO-7184 Component menu can indicate error with double article no, when the article no is ok
AUTO-7104 Tegningshoved: Gentagelser virker ikke på alle felter